

# HOW TO RE-INK MAXLIGHT, SLIM AND SUPER SLIM STAMPS

## RE-INKING MAXLIGHT



1 Remove handle from the MaxLight mount by pulling upwards.



2 Select right colour of MaxLight re-fill ink and add a few drops in each ink port.



3 Put handle back onto mount. Let ink migrate overnight and test stamp. Repeat steps if necessary.

## RE-INKING MAXLIGHT PRE-ASSEMBLED



1 Slide die box out of MaxLight mount and place it on a piece of paper.



2 Select right colour of MaxLight re-fill ink and add a few drops into slotted back of die box.



3 Let ink soak in and slide die box back into mount. Wait 45-60 minutes for ink to migrate and test stamp. Repeat steps if necessary.

## RE-INKING SLIM STAMP



1 Pull off the cover lens from Slim Stamp mount.\*



2 Remove the index card.



3 Select right colour of MaxLight re-fill ink and add a few drops into the cavities.



4 Let ink soak in and put index card and cover lens back in place. Wait 45-60 minutes for ink to migrate and test stamp. Repeat steps if necessary.

## RE-INKING SUPER SLIM



1 Pull off the cover lens from Super Slim mount.



2 Remove the index card.



3 Select right colour of MaxLight re-fill ink and add a few drops into the cavities.



4 Let ink soak in and put index card and cover lens back in place. Wait 45-60 minutes for ink to migrate and test stamp. Repeat steps if necessary.